

# **BARNES TO MOULAMEIN**

### **BROAD GAUGE**

## **CLASS OF LOCOMOTIVE AND PERMITTED SPEEDS (KM/H)**

		CI	CLASS OF LOCOMOTIVE			
		G, XR, BL	A, B,GM, N, S	X, H, P, T, Y		
BARNES and MOULAMEIN	Freight	-		30		
Except Over Edward River Bridge at 371.001 km on	Freight	-		15		
Up side of Moulamein						

Note Trains do not operate BARNES – MOULAMEIN line without prior approval.

#### **SPECIAL SPEED RESTRICTIONS**

No Special Speed Restrictions apply.

3. RULING GRADE LOADS (TONNES)													
SECTION		CLASSES OF LOCOMOTIVES											
	G, XR, BL	N	GM, S, X	Mod A	Non- Mod A solo or multi with A	Non- Mod A multi with other class	В	H solo or multi with H, P, T or Y	H multi with other class	T or P solo or multi with H, P, T or Y	T or P multi with other class	Y solo or multi with T, Y, H or P	Y multi with other class
DOWN													
Barnes to													
MOULAMEIN		2650	2370	2500	2500	2500	2070	1900	1710	1700	1530	850	770
UP													
Moulamein to BARNES		4180	4180	4180	4180	3760	4180	3140	2830	2930	2460	1940	1740

## **SAFEWORKING SYSTEMS**

	STATUS – ATTENDED	STATUS – UNATTENDED
BARNES	Attended Junction Station	Unattended Junction Station
MOULAMEIN	Unattended location	Unattended Train Order Terminal Station

Train Order Working is in force between BARNES to MOULAMEIN.

A Proceed and Return Train Order may be issued between ECHUCA / BARNES and MOULAMEIN.

### **SPECIAL NOTES**

No Special Notes.

#### DISTANCES FROM MELBOURNE AND CLEAR LENGTH OF CROSSING ROADS

LOCATION	MARKED DISTANCE FROM MELBOURNE (KM)	CLEAR LENGTH OF CROSSING ROADS (LENGTH IN METRES)		
	(VIA SEYMOUR)	NO. 1	NO. 2	
BARNES	245.120			
WOMBOOTA	262.505			
BUNNALOO	278.700			
CALDWELL	297.127			
WAKOOL	318.021			
BURRABOI	329.065			
MOULAMEIN	372.408	378	378	

## **NETWORK SERVICE PLAN**







# **BARNES TO MOULAMEIN**

## **BROAD GAUGE**

## 7. TRACK CLASS

Track is maintained to CLASS 4 standards.

## 8. PROTECTED LEVEL CROSSINGS

No Protected Level Crossings.